

# RAYNOX Camcorder Cross Reference Table for Fisheye Lens



Camera Maker	Camera Model	HD-FXR180 (Diagonal)	DCR-CF185PRO(Circular)	DCR-FE180PRO(Diagonal)	XL-3000PRO(0.3X)	MX-3062PRO(0.3X)	MX-3000PRO(0.3X)	HD-3032PRO(0.3X)
SONY	HDR-FX7/FX7E,HVR-V1/V1U/V1E/V1N		Direct mount*9	Direct mount*10	Direct mount	Direct mount		Direct mount
	HDR-CX7/CX7KE/CX7EK/CX7E/CX7K/CX6EK							RA3730(Included) *1
	HDR-UX1							Direct mount
	HDR-SR8/SR8E,HDR-SR7/SR7E							RA3730(Included) *1
	HDR-SR1							RA3730(Included) *1
	HDR-HC3							RA3730(Included) *1
	HDR-FX1/HVR-Z1/Z1U/Z1E	Direct mount						Direct mount
	HDR-HC7/HC7E, HDR-HC5/HC5E, HDR-UX7/UX7E, HDR-UX5/UX5E							Direct mount
	HDR-HC1/HVR-A1		RA6252(Included)+RA5237A*8	RA6252(Included)+RA5237A*7				Direct mount
	DCR-DVR508/DCR-DVD908/908E							Direct mount
	DCR-DVD405/403/505							RA3730(Included)
	DCR-DVD308/DCR-DVD708/708E							RA3730(Included)
	DCR-SR300/300C/300E							Direct mount
	DCR-SR62/62E							RA3730(Included)
	DCR-SR100/SR60							RA3730(Included)
	DCR-HC96/90							RA3730(Included)
	DCR-HC48							RA3730(Included)
	DCR-HC46/HC41							RA3725
	DCR-VX2100/2000/PD-170/PD-150/DSR-250				RA6258(Included)	Direct mount		Direct mount
	DCR-VX1000					Direct mount		
	CCD-TRV126							Direct mount
	DCR-TRV900					Direct mount		
	DCR-TRV950/PDX10				RA6252(Included)+RA5237A	RA5237A		Direct mount
DCR-TRV70K/50					RA5237A			
DCR-HC1000					RA5237A			
DCR-PC300/120					RA5237A			
DCR-PC109/HC40/HC30							RA3725	
Canon	XH-G1/XH-A1			RA6272				
	XL1/XL2/XL H1 16X*20X Zoom							
	HV20							
	HV10							Direct mount
	HR10							Direct mount
	DM-DC40					RA5237A		Direct mount
	DM-DC20							RA3727P5(Included)
	DM-FV500(ZR 100/MV 790/800/800i)							RA3728P5
	IXY DV M5(Optura 600A/MVX IE)							RA3734P5(Included)
	IXY DV S1(Optura S1/MVX1Si)							RA3727P5(Included)
	IXY DV5(Elura 50/MV 6iMC)/DV3(Elura 40MC/MV5iMC)							RA3728P5
	FV M300(Elura 100/MVX 430/450/460)							RA3727P5(Included)
	FV M1(Optura Xi/MVX3i)					RA5246		
	XV-1(GL1/XM1)/XV-2(GL2/XM2)			RA6258(Included)	Direct mount	RA5243A		Direct mount
PV130								
Panasonic	HDC-SD3/HDC-SD1, HDC-DX3/HDC-DX1							RA3743(Included)*6
	HDC-SD5/SD5EG,HDC-SX5							Direct mount*3
	AG-DVX100A/100AP/100AE/102AEN/AG-DVC180AMC							
	AG-DVX100B/100BP/100BE/102BEN/AG-DVC180BMC							
	AG-HVX200/AG-HVX200P/AG-HVX200E/AG-HVX200MC/AG-HVX202EN							
	VDR-D310							Direct mount
	VDR-D400							RA3743(Included)
	VDR-D300/D250					RA5237A		Direct mount
	SDR-S100/S200							Direct mount*3
	NV-GS320							Direct mount
	NV-GS500/400					RA5243A		RA3743(Included)*3
	NV-GS300					RA5237A		Direct mount
	NV-GS250					RA5243A		RA3743(Included)*3
	VDR-M30K							
	NV-GS55/GS50							
JVC	GZ-HD3/HD7				RA5246			
	GZ-MG275/MG255							RA37305P5(Included)*5
	GZ-MG575/MG555							
	GZ-MG505							Direct mount*3*4
	GZ-MG77/MG67/MG70/MG50/MG40							RA37305P5(Included)
	GZ-MG47							RA37305P5(Included)*3
	GR-D650							RA37305P5(Included)
	GR-D350							RA3727P5(Included)
	GR-D250							RA3727P5(Included)
	GZ-MC500					RA5237A		Direct mount
	GZ-MC200/MC100							RA37305P5(Included)
	GR-DV3000/DV3500					Direct mount		
	GR-DV5000					Direct mount		
	GR-DV900K/DV700K					Direct mount		
	GR-DV500					RA5237A		
GR-X5					RA5237A			
HITACHI	DZ-BD7H/7HA/7HE, DZ-BD70/70A/70E							RA3743(Included)*5
	DZ-HS303							Direct mount*3
	DZ-GX3300							Direct mount
	DZ-GX3200							RA3734P5(Included)*3
	DZ-GX3100							RA37305P5(Included)
TOSHIBA	GSC-R60/R30/MEHV10							RA37305P5(Included)

\*1:Vignetting occurs at 4:3 Still mode \*2:Vignetting occurs at Still/Video/under scanning mode \*3:Remove camera's cosmetic ring or hood before attaching the Raynox lens \*4:Vignetting occurs at Still/16:9 Video mode when used with QC-303 \*5:Vignetting occurs at Still mode \*6:Slight vignetting occurs at under scanning/still mode \*7:Unable to take a full diagonal fisheye image \*8:Unable to take circular fisheye image other than at 4:3 Still mode \*9:may not produce either circular or diagonal fish-eye image \*10:Slight vignetting may occur in (under scanning) mode and still image mode in maximum wideangle zooming

Remote control function and internal video light/Flash may not work properly with conversion lens attached.