

Camera Maker	Camera Model	DVR-5002(0.5X)	DCR-5000(0.5X)	HD-5050PRO(0.5X)	HD-6600PRO-43/49/52/55/58(0.66X)	DCR-730(0.7X)	DVM-700(0.7X)	HD-7062PRO(0.7X)	HD-7000PRO(0.7X)	DCR-7900ZD(0.79X)	HDP-6000EX(0.79X)	DVR-1002(0.65X+1.5X)	QC-505(0.5X)QC-707(0.7X)	XL-5000PRO(0.5X)/XL-7000PRO(0.7X)	
SONY	HDR-FX7/FX7E,HVR-V1/V1U/V1E/V1N		RA5262A			RA5262A		Direct mount			RA7262			Direct mount	
	HDR-CX7/CX7KE/CX7EK/CX7E/CX7K/CX6EK	Direct mount*1	RA5237A	Direct mount *1	HD-6600PRO-52+RA5237A	RA5237A			RA5837			Direct mount	Direct mount		
	HDR-UX1	RA3730(Included)		RA3730(Included) *1			Direct mount *1						RA3730(Included)	Direct mount	
	HDR-SR8/SR8E,HDR-SR7/SR7E	Direct mount*1	RA5237A	Direct mount *1	HD-6600PRO-52+RA5237A	RA5237A			RA5837				Direct mount	Direct mount	
	HDR-SR1	RA3730(Included)		RA3730(Included) *1			Direct mount *1						RA3730(Included)	Direct mount	
	HDR-HC3	RA3730(Included)		RA3730(Included) *1			Direct mount *1						RA3730(Included)	Direct mount	
	HDR-FX1/HVR-Z1/Z1U/Z1E										RA6272	Direct mount			
	HDR-HC7/HC7E, HDR-HC5/HC5E, HDR-UX7/UX7E, HDR-UX5/UX5E	Direct mount*1	RA5237A	Direct mount *1	HD-6600PRO-52+RA5237A	RA5237A				RA5837			Direct mount	Direct mount	
	HDR-HC1/HVR-A1		RA5237A	Direct mount *1	HD-6600PRO-52+RA5237A	RA5237A				RA5837					
	DCR-DVR508/DCR-DVD908/908E	Direct mount	RA5237A	Direct mount	HD-6600PRO-52+RA5237A	RA5237A				RA5837			Direct mount	Direct mount	
	DCR-DVD405/403/505	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-DVD308/DCR-DVD708/708E	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-SR300/300C/300E	Direct mount	RA5237A	Direct mount	HD-6600PRO-52+RA5237A	RA5237A				RA5837			Direct mount	Direct mount	
	DCR-SR62/62E	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-SR100/SR60	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-HC96/90	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-HC48	RA3730(Included)		RA3730(Included)			Direct mount						RA3730(Included)	Direct mount	
	DCR-HC46/H41	RA3725		RA3725			RA3025						RA3725	RA3725	
	DCR-VX2100/2000/PD-170/PD-150/DSR-250		RA5258A			HD-6600PRO-58*6	RA5258A				Direct mount				Direct mount
	DCR-VX1000					HD-6600PRO-52									Direct mount
	CCD-TRV126	Direct mount		Direct mount											Direct mount
	DCR-TRV900					HD-6600PRO-52									Direct mount
	DCR-TRV950/PDX10		RA5237A	Direct mount		HD-6600PRO-52+RA5237A	RA5237A			RA5837				Direct mount	RA5237A
	DCR-TRV70K/50					HD-6600PRO-52+RA5237A									RA5237A
	DCR-HC1000					HD-6600PRO-52+RA5237A									RA5237A
DCR-PC300/120					HD-6600PRO-52+RA5237A									RA5237A	
DCR-PC109/H40/H41	RA3725		RA3725				RA3025						RA3725	RA3725	
Canon	XH-G1/XH-A1													Direct mount	
	XL1/XL2/XL H1 16X*20X Zoom													Direct mount	
	HV20		RA5243A		HD-6600PRO-52+RA5243A	RA5243A				RA5843					
	HV10	Direct mount*2		Direct mount*2		RA5237A								Direct mount	
	DM-DC40	Direct mount												Direct mount	
	DM-DC20	RA3727P5(Included)		RA3727P5(Included)			RA3027P5(Included)							Direct mount	
	DM-FV500(ZR 100/MV 790/800/800i)	RA3728P5		RA3728P5										Direct mount	
	IXY DV M5(Optura 600A/MVX iE)	RA3734P5(Included)		RA3734P5(Included)										Direct mount	
	IXY DV S1(Optura S1/MVX1Si)	RA3727P5(Included)		RA3727P5(Included)			RA3027P5(Included)							Direct mount	
	IXY DV5(EIura 50/MV 6IMC)/DV3(EIura 40MC/MV5IMC)	RA3728P5		RA3728P5										Direct mount	
	FV M300(EIura 100/MVX 430/450/460)	RA3727P5(Included)		RA3727P5(Included)			RA3027P5(Included)							Direct mount	
	FV M1(Optura Xi/MVX3i)					HD-6600PRO-52+RA5246								RA5246	
	XV-1(GL1/XM1)/XV-2(GL2/XM2)		RA5258A			HD-6600PRO-58	RA5258A				Direct mount				Direct mount
	PV130					HD-6600PRO-43									RA5243A
	Panasonic	HDC-SD3/HDC-SD1, HDC-DX3/HDC-DX1				HD-6600PRO-43									
AG-DVX100A/100AP/100AE/102AEN/AG-DVC180AMC														Direct mount	
AG-DVX100B/100BP/100BE/102BEN/AG-DVC180BMC														Direct mount	
AG-HVX200/AG-HVX200P/AG-HVX200E/AG-HVX200MC/AG-HVX202EN														RA7282*7	
VDR-D310		Direct mount		Direct mount										Direct mount	
VDR-D400		RA3743(Included)		RA3743(Included)									RA3743(Included)	RA3743	
VDR-D300/D250		Direct mount		Direct mount										Direct mount	
SDR-S100/S200		Direct mount*3		Direct mount*3										Direct mount	
NV-GS320		Direct mount		Direct mount										Direct mount	
NV-GS500/400		RA3743(Included)*3		RA3743(Included)*3	HD-6600PRO-43								RA3743(Included)*3	RA3743*3	RA5243A
NV-GS300		Direct mount		Direct mount										Direct mount	
NV-GS250		RA3743(Included)*3		RA3743(Included)*3										Direct mount	
VDR-M30K							RA30305P5(Included)								RA5243A
NV-GS55/GS50							RA3027P5(Included)								
JVC		GZ-HD7		RA5246			RA5246								RA5246
	GZ-MG275/MG255	RA37305P5(Included)*5		RA37305P5(Included)*5						RA5852+RA5246				Direct mount	
	GZ-MG575/MG555		RA5246		RA5246	RA5246									
	GZ-MG505	Direct mount*3*2		Direct mount*3*2										Direct mount	
	GZ-MG77/MG67/MG70/MG50/MG40	RA37305P5(Included)		RA37305P5(Included)			RA30305P5(Included)							Direct mount	
	GR-MG47	RA37305P5(Included)*3		RA37305P5(Included)*3			RA30305P5(Included)*3							Direct mount	
	GR-D650	RA37305P5(Included)		RA37305P5(Included)			RA30305P5(Included)							Direct mount	
	GR-D350	RA3727P5(Included)		RA3727P5(Included)			RA3027P5(Included)							Direct mount	
	GR-D250	RA3727P5(Included)		RA3727P5(Included)										Direct mount	
	GZ-MC500	Direct mount		Direct mount	HD-6600PRO-52+RA5237A									Direct mount	
	GZ-MC200/MC100	RA37305P5(Included)		RA37305P5(Included)			RA30305P5(Included)							Direct mount	
	GR-DV3000/DV3500				HD-6600PRO-52										Direct mount
	GR-DV5000				HD-6600PRO-52										Direct mount
	GR-DV900K/DV700K				HD-6600PRO-52										Direct mount
	GR-DV500				HD-6600PRO-52+RA5237A										RA5237A
GR-X5				HD-6600PRO-52+RA5237A										RA5237A	
HITACHI	DZ-HS303	Direct mount*3		Direct mount*3										Direct mount	
	DZ-GX3300	Direct mount		Direct mount										Direct mount	
	DZ-GX3200	RA3734P5(Included)*3		RA3734P5(Included)*3										Direct mount	
	DZ-GX3100	RA37305P5(Included)		RA37305P5(Included)			RA30305P5(Included)							Direct mount	
TOSHIBA	GSC-R60/R30/MEHV10	RA37305P5(Included)		RA37305P5(Included)			RA30305P5(Included)							Direct mount	

*1:Vignetting occurs at 4:3 Still mode *2:Vignetting occurs at Still/Video/under scanning mode *3:Remove camera's cosmetic ring or hood before attaching the Raynox lens *5:Vignetting occurs at Still mode *6:Vignetting occurs at under scanning mode *7:Slight Vignetting occurs

Remote control function and internal video light/Flash may not work properly with conversion lens attached.